



SECTION A-A

NOTES

1. SAWCUT SIDEWALK TO FULL DEPTH. MINIMUM LIMIT OF CONCRETE REMOVAL AND REPLACEMENT IS ENTIRE AREA BETWEEN PANEL DIVISION MARKS.
2. CURB SHALL BE CORE DRILLED.
3. MATCH THICKNESS OF EXISTING CURB AND SIDEWALK.
4. FINISH SIDEWALK AND CURB (TOP AND FACE) FLUSH WITH EXISTING ADJACENT LINE AND GRADE.
5. THE MINIMUM 28-DAY COMPRESSIVE STRENGTH OF ALL CONCRETE SHALL BE 4000 P.S.I.
6. INSTALL DRAIN PIPE PERPENDICULAR TO THE CURB THROUGH THE RIGHT OF WAY.

<b>CITY OF ALBANY, OREGON</b> <b>PUBLIC WORKS DEPARTMENT</b>		
<b>INSTALLATION OF CURB DRAINS</b> <b>UNDER EXISTING SIDEWALKS</b>		
NO SCALE	OCTOBER 2013	NO. 307